

FLUKE®

**A family of DMMs
designed by you,
engineered by Fluke.**

**Fluke 117 for commercial electricians
Fluke 116 for HVAC/R professionals**



Fluke 117: Electricians' Multimeter with non-contact Voltage

The Fluke 117 is the meter for demanding settings like commercial buildings, hospitals and schools.

New DMM functionality designed to make the electrician's job easier than ever before. Check out these new, innovative features.

VoltAlert™—non-contact voltage detection

- Sense the presence of ac voltage without carrying a second tool
- Quickly determine proper grounding with visual indicator

Auto-V—automatic volts detection

- Automatically determine ac/dc voltage—eliminating guesswork
- Correctly displays the voltage measurement without extra steps

LoZ—Low impedance input

- Reduces chance of false readings due to ghost voltage with new, low impedance design
- Safer troubleshooting in high-energy 3-phase distribution panel with IEC 61010 ratings

Other major Fluke 117 features:

- True-rms for accurate measurement on non-linear loads
- 20 A measurements (30 seconds momentary, 10 A continuous)
- Resistance, continuity, frequency and capacitance
- Min/Max/Average to record signal fluctuations



Save 20 % - buy the complete Electrician's Combo Kit

- Fluke 117 Multimeter
- Fluke 322 Clamp
- ToolPak™ Meter hanger
- Soft carrying case
- Test leads



Go to www.fluke.com for more information.

Check out the virtual product demo at:

fluke.com/dmms_116_117

Fluke 116 HVAC Multimeter with Temperature and Microamps

The Fluke 116 has the functions you need to quickly troubleshoot problems with HVAC equipment and flame sensors.



Built-in thermometer gives you versatility to perform a wide range of HVAC/R tests. Here are just a few examples:

Measure superheat and subcooling.

- Measure key temperatures and pressures. Use the Fluke 116 with a Fluke velcro pipeclamp (included in kit) and the PV350 (optional) pressure module to determine superheat and subcooling values.
- Detect problems like a clogged filter drier, undercharge, overcharge, faulty metering device or improper airflow, liquid line restriction or insufficient water flow.

Troubleshoot the defrost control on a heat pump

- Check the temperature of the air coil
- Confirm when the defrost cycle starts and ends

Take temperature surveys

- Test out compressor heads, oil sumps, evaporator coils and suction lines, plus discharge lines, condenser coils and the liquid line

Microamps measurement for testing flame sensors

When a furnace flame will not stay lit, use the Fluke 116 microamps measurement to troubleshoot the flame rod circuit.

LoZ reduces chance of false readings due to ghost voltage.

(See Fluke 117 for more details about the LoZ function.)

Save 20 % - HVAC Technician's Combo Kit

The complete solution: HVAC Technician's Combo Kit

- | | |
|--------------------------------------|-----------------------------------|
| • Fluke 116 Multimeter | • ToolPak™ Meter hanger |
| • Fluke 62 Mini Infrared Thermometer | • Velcro® Pipe Clamp Thermocouple |
| • 80AK Thermocouple Adapter | • Soft carry case |
| • 80BK Integrated Temperature Probe | • Test leads |



Test faster and safer with a new Fluke

FLUKE®



Function/Feature	Benefit	Original 112	New 117	Original 116	New 116
VoltAlert – non-contact voltage indicator	Separate voltage detector not required	NO	YES	NO	NO
AutoV – determines ac/dc voltage	Correctly display voltage measurements without extra steps	NO	YES	YES	YES
LoZ – low impedance input	Reduces chance of false readings	NO	YES	YES	YES
Frequency	Measure frequency with one tool	YES	YES	NO	YES
Basic dc accuracy	Precise measurements in a handheld	0.7 %	0.5 %	0.9 %	0.5 %
Analog bar graph	Better accuracy when monitoring measurement changes	YES	YES	NO	YES
Compact ergonomic design	One-handed operation	NO	YES	NO	YES
Large white LED backlit display/larger digits	Easier to read in dark locations	NO	YES	NO	YES
Display hold/Auto (Touch) Hold	Hold measurements for later use	YES	YES	NO	YES
ToolPak/Magnetic hanger compatible	Position meter for easy viewing	YES	YES	NO	YES

Also available:

Fluke 115 Multimeter

A compact true-rms meter for field service technicians

- Resistance, continuity, frequency, capacitance, and diode test
- Measures 20 A (30 seconds momentary; 10 A continuous)

Fluke 114 Multimeter

A compact true-rms meter for electrical troubleshooting

- AutoVolt for automatic ac/dc voltage selection
- Resistance and continuity



Fluke Accessories

Get the most out of every Fluke tool with the right accessories.

Electricians Accessories

ToolPak™ Magnetic meter hanging solution. Hang the 116 or 117 so you can work with both hands free or leave the meter in place to log data while you do other work. For more information visit www.fluke.com/tpak

AC220 SureGrip™ Alligator Clips.

Designed to improve steadiness in slippery hands. Rubber overmolded surfaces and finger-hugging curves give the user a comfortable, reliable grip. Visit www.fluke.com/AC220

C50 Carrying Case. Protect your meter with this rugged zippered carrying case featuring inside pocket belt loop and inside meter strap. For more information visit www.fluke.com/accessories

HVAC Accessories

80PK-27 SureGrip™ Industrial Surface Temperature Probe. Type-K thermocouple for surfaces in rugged environments – measurement range: -127 to 600 °C. For more information visit www.fluke.com/80PK-27

80PK-3A Surface Probe. Type-K thermocouple for flat or curved surfaces such as plates and rollers – measurement range 0 to 260 °C. For more information visit www.fluke.com/80PK-3A

80PK-8 Pipe Clamp Temperature Probe. Type-K thermocouple for fast temperature and superheat measurements of pipe surfaces – measurement range -29 to 149 °C for pipe diameters from 6.4 to 34.9mm. For more information visit www.fluke.com/80PK-8

Ordering Information:

Fluke-117/322 ... Electricians Combo Kit

Fluke-117 Electricians Multimeter

Fluke-116/62 HVAC Combo Kit

Fluke-116 HVAC Multimeter

Fluke-115 Multimeter

Fluke-114 Electrical Multimeter

Fluke. Keeping your world up and running.™

Fluke Corporation

PO Box 9090, Everett, WA USA 98206

Fluke Europe B.V.
PO Box 1186, 5602 BD
Eindhoven, The Netherlands

For more information call:
In the U.S.A. (800) 443-5853 or
Fax (425) 446-5116
In Europe/M-East/Africa (31 40) 2 675 200 or
Fax (31 40) 2 675 222
In Canada (800) 36-FLUKE or
Fax (905) 890-6866
From other countries +1 (425) 446-5500 or
Fax +1 (425) 446-5116
Web access: <http://www.fluke.com/>

©2006 Fluke Corporation. All rights reserved.
Specifications subject to change without notice.
Printed in U.S.A. 9/2006 2634070 B-EN-N Rev A

Instantly get more product information: fluke.com/dmms_116_117